

Acue Lighting Pixel 8 LED

<u>DMX 2 Channel (Mode 1)</u>		
<u>Channel</u>	<u>DMX Range</u>	<u>Function</u>
Channel 1	0~11	Off
	12~23	Red
	24~35	Green
	36~47	Blue
	48~59	Yellow
	60~71	Purple
	72~83	Cyan
	84~95	White
	96~107	Program 1
	108~119	Program 2
	120~131	Program 3
	132~143	Program 4
	144~155	Program 5
	156~167	Program 6
	168~179	Program 7
	180~191	Program 8
	192~203	Program 9
204~215	Program 10	
216~227	Program 11	

	228~239	Program 12
	240~251	Program 13
	252~255	Sound Mode
Channel 2	0~255	Function Speed: Slow to Fast / Sound Sensitivity

DMX 3 Channel (Mode 2)

<u>Channel</u>	<u>DMX Range</u>	<u>Function</u>
Channel 1	0~255	R Dimmer
Channel 2	0~255	G Dimmer
Channel 3	0~255	B Dimmer

DMX 4 Channel (Mode 3)

<u>Channel</u>	<u>DMX Range</u>	<u>Function</u>
Channel 1	0~255	R Dimmer
Channel 2	0~255	G Dimmer
Channel 3	0~255	B Dimmer
Channel 4	0~255	Master Dimmer

DMX 14 Channel (Mode 4)

<u>Channel</u>	<u>DMX Range</u>	<u>Function</u>
Channel 1	0~255	R Dimmer
Channel 2	0~255	G Dimmer

Channel 3	0~255	B Dimmer
Channel 4	0~255	R Dimmer
Channel 5	0~255	G Dimmer
Channel 6	0~255	B Dimmer
Channel 7	0~255	R Dimmer
Channel 8	0~255	G Dimmer
Channel 9	0~255	B Dimmer
Channel 10	0~255	R Dimmer
Channel 11	0~255	G Dimmer
Channel 12	0~255	B Dimmer
Channel 13	0~255	Flash: Slow to Fast
Channel 14	0~255	Master Dimmer

DMX 7 Channel (Mode 5)

<u>Channel</u>	<u>DMX Range</u>	<u>Function</u>
Channel 1	0~255	R Dimmer
Channel 2	0~255	G Dimmer
Channel 3	0~255	B Dimmer
Channel 4	0~11	Off
	12~23	Red
	24~35	Green
	36~47	Blue
	48~59	Yellow
	60~71	Purple
	72~83	Cyan
	84~95	White
	96~107	Program 1
	108~119	Program 2
	120~131	Program 3
	132~143	Program 4
144~155	Program 5	

	156~167	Program 6
	168~179	Program 7
	180~191	Program 8
	192~203	Program 9
	204~215	Program 10
	216~227	Program 11
	228~239	Program 12
	240~251	Program 13
	252~255	Sound Mode
Channel 5	0~255	Function Speed: Slow to Fast / Sound Sensitivity
Channel 6	FLASH	
	0~4	Off
	5~255	Slow to Fast
Channel 7	0~255	Master Dimmer

DMX 26 Channel (Mode 6)

<u>Channel</u>	<u>DMX Range</u>	<u>Function</u>
Channel 1	0~255	R Dimmer
Channel 2	0~255	G Dimmer
Channel 3	0~255	B Dimmer
Channel 4	0~255	R Dimmer
Channel 5	0~255	G Dimmer
Channel 6	0~255	B Dimmer
Channel 7	0~255	R Dimmer
Channel 8	0~255	G Dimmer
Channel 9	0~255	B Dimmer
Channel 10	0~255	R Dimmer
Channel 11	0~255	G Dimmer
Channel 12	0~255	B Dimmer
Channel 13	0~255	R Dimmer
Channel 14	0~255	G Dimmer

Channel 15	0~255	B Dimmer
Channel 16	0~255	R Dimmer
Channel 17	0~255	G Dimmer
Channel 18	0~255	B Dimmer
Channel 19	0~255	R Dimmer
Channel 20	0~255	G Dimmer
Channel 21	0~255	B Dimmer
Channel 22	0~255	R Dimmer
Channel 23	0~255	G Dimmer
Channel 24	0~255	B Dimmer
Channel 25	FLASH	
	0	Off
	1~255	Slow to Fast
Channel 26	0~255	Master Dimmer