

Acue Lighting Storm 36x10W Zoom Wash

<u>DMX 16 Channel</u>		
<u>Channel</u>	<u>DMX Range</u>	<u>Function</u>
CH1	0~255	Pan
CH2	0~255	Tilt
CH3	0~255	Pan / Tilt Speed: Fast to Slow
CH4	0~255	Master Dimmer: Linear 0-100%
CH5	0~255	R Dimmer: Linear 0-100%
CH6	0~255	G Dimmer: Linear 0-100%
CH7	0~255	B Dimmer: Linear 0-100%
CH8	0~255	W Dimmer: Linear 0-100%
STROBE		
CH9	0~10	No Function
	11~255	Shutter Speed: Slow to Fast
CH10	0~255	Focus
Color Selection		
CH11	0~10	No Function
	11~210	Color Selection
	211~225	Color Jump Change
	226~240	Gradual Color Change
	241~255	Color Pulse
CH12	0~255	Color Change Speed: Slow to Fast
CH13	0~255	Pan Fine
CH14	0~255	Tilt Fine
RESET		
CH15	0~254	No Function
	255	Reset
CH16	NA	Empty

<u>DMX 24 Channel</u>		
<u>Channel</u>	<u>DMX Range</u>	<u>Function</u>
CH1	0~255	Pan
CH2	0~255	Tilt
CH3	0~255	Pan / Tilt Speed: Fast to Slow
CH4	0~255	Master Dimmer: Linear 0-100%
CH5	0~255	R Dimmer 1: Linear 0-100%
CH6	0~255	G Dimmer 1: Linear 0-100%
CH7	0~255	B Dimmer 1: Linear 0-100%
CH8	0~255	W Dimmer 1: Linear 0-100%
CH9	0~255	R Dimmer 2: Linear 0-100%
CH10	0~255	G Dimmer 2: Linear 0-100%
CH11	0~255	B Dimmer 2: Linear 0-100%
CH12	0~255	W Dimmer 2: Linear 0-100%
CH13	0~255	R Dimmer 3: Linear 0-100%
CH14	0~255	G Dimmer 3: Linear 0-100%

CH15	0~255	B Dimmer 3: Linear 0-100%
CH16	0~255	W Dimmer 3: Linear 0-100%
CH17	STROBE	
	0~10	No Function
	11~255	Shutter Speed: Slow to Fast
CH18	0~255	Focus
CH19	Color Selection	
	0~10	No Function
	11~210	Color Selection
	211~225	Color Jump Change
	226~240	Gradual Color Change
	241~255	Color Pulse
CH20	0~255	Color Change Speed: Slow to Fast
CH21	0~255	Pane Fine
CH22	0~255	Tilt Fine
CH23	Reset	
	0~254	No Function
	255	Reset
CH24	NA	Empty