

Acue Lighting 2R Beam

<u>DMX 20 Channel</u>		
<u>Channel</u>	<u>DMX Range</u>	<u>Function</u>
CH1	COLOR SELECTION	
	0~9	White
	10~18	Red
	19~27	Yellow
	28~36	Blue
	37~45	Green
	46~54	Pink
	55~63	Orange
	64~73	Aqua
	74~82	Lime
	83~91	Magenta
	92~100	3800K CCW
	101~109	5000K CCW
	110~118	4500K CCW
	119~126	Ultraviolet
127	STOP	
128~255	Color Wheel Rotation Clockwise	

CH2	STROBE	
	0~3	Shutter Closed
	4~7	Shutter Open
	8~97	Shutter 1: Slow to Fast
	98~101	Shutter Closed
	102~126	Shutter 2: Slow to Fast
	127~151	Shutter 3: Fast to Slow
	152~155	Shutter Open
	156~180	Shutter 4: Slow to Fast
	181~205	Shutter 5: Fast to Slow
	206~209	Shutter Open
	210~249	Shutter 6: Slow to Fast
250~255	Shutter Open	
CH3	0~255	Master Dimmer: 0-100%
CH4	GOBO	
	0~3	White
	4~7	Gobo 1
	8~11	Gobo 2
	12~15	Gobo 3
	16~19	Gobo 4
	20~23	Gobo 5
	24~27	Gobo 6
	28~31	Gobo 7
	32~35	Gobo 8
	36~39	Gobo 9
	40~43	Gobo 10
	44~47	Gobo 11
	48~51	Gobo 12
52~55	Gobo 13	

	60~103	CW Gobo Rotation: Fast to Slow
	104~147	CCW Gobo Rotation: Slow to Fast
	148~255	GOBO SHAKE IN ORDER
CH5	PRISM	
	0~127	Prism Off
	128~255	Prism On
CH6	PRISM ROTATION	
	0~63	Indexation
	64~127	CW Rotation: Slow to Fast
	128~191	CCW Rotation: Slow to Fast
	192~207	90° Shift
	208~255	360° Shift
CH7	0~255	Focus
CH8	0~255	Pan
CH9	0~255	Pan 16 Bit
CH10	0~255	Tilt
CH11	0~255	Tilt 16 Bit
CH12	0~255	Pan Tilt Speed
CH13	0~255	Empty
CH14	Lamp Control	
	0~159	No Function
	160~191	Lamp Off
	192~223	No Function
	224~255	Lamp On
CH15	0~255	Empty
CH16	0~255	Reset
CH17	0~255	Empty
CH18	0~255	Empty
CH19	0~255	Empty
CH20	0~255	Empty